


DATE: 08/20/99 TIME: 00:00

| DRAWING | SHEET NO. | TITLE | DATE | REVISION / DATE | A/C CONFIGURATION | | | |
|----------------|-----------|--|----------|-----------------|------------------------------|-----------------------|---------------------------------|---|
| | | | | | LOCKHEED L-1011-385-1 SERIES | LOCKHEED L-1011-385-3 | LOCKHEED L-1011-385-1 FREIGHTER | LOCKHEED L-1011-385-1 FREIGHTER W/ SMALL C1 COMPARTMENT |
| TFC03-0121-() | 1 | FAULT PANEL PC BOARD ASSEMBLY & WIRING DIAGRAM | 04/98 | E-11/14/01 | X | X | X | X |
| TFC03-0121-() | 2 | FAULT PANEL PC BOARD ASSEMBLY & WIRING DIAGRAM | 04/98 | C-11/14/01 | X | X | X | X |
| TFC03-0121-() | 3 | FAULT PANEL PC BOARD ASSEMBLY & WIRING DIAGRAM | 04/98 | C-09/24/98 | X | X | X | X |
| TFC03-0121-() | 4 | FAULT PANEL PC BOARD ASSEMBLY & WIRING DIAGRAM | 12/29/00 | IR-12/29/00 | X | X | X | X |
| TFC03-0167-() | 1 | SPECIFICATION CONTROL DWG. MASTER KIT, SMOKE DETECTION/SUPPRESSION | 08/20/99 | A-02/19/00 | X | X | | |
| TFC03-0168-() | 1 | SPECIFICATION CONTROL DWG. HARNESS ASSEMBLY, SUPPRESSION SYSTEM KIT | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC03-0169 | 1 | SPECIFICATION CONTROL DWG. WIRING DIAGRAM SMOKE DETECTION SYSTEM | 08/20/99 | B-02/19/00 | X | X | | |
| TFC03-0170 | 1 | SPECIFICATION CONTROL DWG. WIRING DIAGRAM CARGO FIRE SUPPRESSION | 08/20/99 | A-02/19/00 | X | X | | |
| TFC03-0171 | 1 | SPECIFICATION CONTROL DWG. DETECTION HARNESS LOOSE PARTS KIT | 08/20/99 | B-08/21/00 | | X | | |
| TFC03-0172-() | 1 | SPECIFICATION CONTROL DWG. HOUSING, ASSEMBLY FIRE DETECTION, SYSTEM | 08/20/99 | B-02/19/00 | X | X | | |
| TFC03-0173 | 1 | SPECIFICATION CONTROL DWG. DETECTOR ASSEMBLY, CONTROL PANEL KIT | 08/20/99 | A-12/08/99 | X | X | | |
| TFC03-0178 | 1 | SPECIFICATION CONTROL DWG. DETECTION HARNESS LOOSE PARTS KIT | 01/10/00 | B-08/21/00 | X | | | |
| TFC03-0214-() | 1 | SPECIFICATION CONTROL DWG. SMOKE DETECTION MASTER KIT | 12/07/00 | A-01/26/01 | | | X | X |
| TFC03-0215-() | 1 | SPECIFICATION CONTROL DWG. HOUSING, ASSY FIRE DETECTION (ONLY) SYSTEM | 12/07/00 | A-02/23/01 | | | X | X |
| TFC03-0216-() | 1 | SPECIFICATION CONTROL DWG. CONTROL PANEL HARNESS ASSEMBLY | 12/07/00 | IR-12/07/00 | | | X | X |
| TFC03-0217-() | 1 | SPECIFICATION CONTROL DWG. DETECTION HARNESS LOOSE PARTS KIT | 12/07/00 | IR-12/07/00 | | | X | X |
| TFC03-0218 | 1 | SPECIFICATION CONTROL DWG. WIRING DIAGRAM SMOKE DETECTION | 12/07/00 | A-02/23/01 | | | X | |
| TFC03-0221 | 1 | SPECIFICATION CONTROL DWG. WIRING DIAGRAM SMOKE DETECTION | 01/26/01 | A-02/17/01 | | | | X |
| TFC04-0059-() | 1-2 | TUBING ASSEMBLY, PARTICULATE FILTER | 03/16/06 | A-11/01/07 | X | X | | |
| TFC05-0037-() | 1 | FAULT BOX | 07/97 | I-11/06/02 | X | X | X | X |
| TFC05-0037-() | 2 | FAULT BOX | 07/97 | I-11/06/02 | X | X | X | X |
| TFC05-0039-() | 1, 3, 5 | LABEL | 05/98 | A-09/24/98 | X | X | X | X |
| TFC05-0050 | 1-2 | FAULT PLATE | 08/20/99 | B-02/15/00 | X | X | | |
| TFC05-0051-() | 1-2 | PLACARDS | 08/20/99 | A-12/06/99 | X | X | | |
| TFC05-0052-() | 1 | CARGO LOADING PLACARD | 08/20/99 | IR-08/20/99 | | X | | |
| TFC05-0052-() | 2 | CARGO LOADING PLACARD | 02/15/00 | IR-02/15/00 | X | | | |
| TFC05-0052-() | 3 | CARGO LOADING PLACARD | 02/15/00 | A-11/10/00 | X | | | |
| TFC05-0060 | 1-2 | FAULT PLATE | 11/10/00 | IR-11/10/00 | | | X | |
| TFC05-0061-() | 1 | PLACARDS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC05-0062 | 1-2 | FAULT PLATE | 12/20/00 | IR-12/20/00 | | | | X |
| TFC05-0072 | 1 | LABEL | 05/25/14 | IR-05/25/14 | X | X | X | X |
| TFC05-0073 | 1 | LABEL | 05/25/14 | IR-05/25/14 | X | X | X | X |
| TFC06-0051-() | 1 | SPECIFICATION CONTROL DWG. HOUSING, ASSEMBLY FIRE DETECTION SYSTEM, | 02/98 | H-12/07/00 | X | X | X | X |
| TFC06-0054-() | 2 | GUARD BAR ASSEMBLY | 11/04/98 | C-05/25/14 | X | X | X | X |
| TFC06-0063-() | 1 | MOUNTING PLATE, FIREX NOZZLE | 05/98 | C-05/06/02 | X | X | | |
| TFC06-0067 | 1 | MOUNTING PLATE, FAULT PANEL ASSEMBLY | 05/98 | B-10/13/98 | X | X | X | X |
| TFC06-0081 | 1 | MOUNTING PLATE, DIVERTER VALVE/METERING VALVE | 01/06/99 | A-04/06/16 | X | X | | |
| TFC06-0096 | 1 | SPECIFICATION CONTROL DWG. ELECTRONIC INTERFACE TRAY ASSEMBLY | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC06-0098-() | 1 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | X | | | |
| TFC06-0098-() | 2 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | X | | | |
| TFC06-0098-() | 3 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | | X | | |
| TFC06-0098-() | 4 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | | X | | |
| TFC06-0098-() | 5 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | | X | | |
| TFC06-0098-() | 6 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | | X | | |
| TFC06-0098-() | 7 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | | X | | |
| TFC06-0098-() | 8 | ANGLE SUPPORT ASSEMBLY, 2500 CU. IN. BOTTLE MOUNTING | 08/20/99 | A-09/24/99 | | X | | |
| TFC06-0099-() | 1 | MOUNTING PLATE ASSEMBLY, 1400 CU. IN. BOTTLE | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC06-0103 | 1 | ENCLOSURE SUPPORT ANGLE | 08/20/99 | IR-08/20/99 | X | X | X | X |
| TFC06-0104 | 1 | BLANKING PLATE | 08/20/99 | IR-08/20/99 | | X | | |
| TFC06-0105-() | 1-3 | SUPPORT BRACKET ASSEMBLY, PRESSURE REGULATOR | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC06-0106 | 1 | SHIM, ENCLOSURE | 08/20/99 | IR-08/20/99 | X | X | X | X |
| TFC06-0107 | 1 | MOUNTING CLIP, ENCLOSURE | 08/20/99 | IR-08/20/99 | X | X | X | X |
| TFC06-0108 | 1 | SHEAR TIE ANGLE | 11/01/99 | IR-11/01/99 | X | X | | |
| TFC06-0112 | 1 | ENCLOSURE SUPPORT ANGLE | 02/15/00 | IR-02/15/00 | X | | X | X |
| TFC06-0122-() | 1 | SPECIFICATION CONTROL DWG. ELECTRONIC INTERFACE TRAY ASSEMBLY | 12/07/00 | IR-12/07/00 | | | X | |
| TFC06-0125-() | 1 | SPECIFICATION CONTROL DWG. ELECTRONIC INTERFACE TRAY ASSEMBLY | 01/26/01 | IR-01/26/01 | | | | X |
| TFC07-0054 | 1-6 | CLASS C CARGO COMP. FPS BILL OF MATERIALS | 08/20/99 | H-07/27/11 | X | X | | |
| TFC07-0054A | 1 | CLASS D CARGO COMP. FPS ENCLOSURE/FIREX PLATE LAYOUT | 08/20/99 | A-12/06/99 | X | | | |
| TFC07-0054A | 2 | CLASS D CARGO COMP. FPS ENCLOSURE/FIREX PLATE LAYOUT | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054B | 1 | CLASS D CARGO COMP. FPS CONTROL PANEL LOCATION INSTRUCTIONS | 08/20/99 | A-02/15/00 | X | X | | |
| TFC07-0054B | 2 | CLASS D CARGO COMP. FPS EXISTING SMOKE DETECTION PANEL MODIFICATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054C | 1 | CLASS D CARGO COMP. FPS CIR. BREAKER LOCATION INSTRUCTIONS | 08/20/99 | A-05/15/00 | X | X | | |
| TFC07-0054D | 1 | CLASS D CARGO COMP. FPS ANNUNCIATOR LOCATION INSTRUCTIONS | 08/20/99 | A-02/15/00 | X | X | | |
| TFC07-0054E | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC07-0054F | 1 | CLASS D CARGO COMP. FPS FAULT PANEL INSTALL. INSTRUCTIONS | 08/20/99 | A-02/15/00 | X | X | | |
| TFC07-0054G | 1 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 08/20/99 | B-01/18/01 | X | X | | |
| TFC07-0054G | 2 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | X | X | | |

| OUTSTANDING ECN'S | |
|-------------------|------------|
| ECN NUMBER | ECN NUMBER |
| | |
| | |
| | |
| | |

| REV | DESCRIPTION | REVISIONS | | | |
|-----|--------------------------|-----------|----------|------------|-------------|
| | | ECN | DATE | REVISED BY | APPROVED BY |
| IR | INITIAL RELEASE | | 08/20/99 | | W.A.E. |
| A | REFER TO DCN FOR CHANGES | | 12/08/99 | | W.A.E. |
| B | REFER TO DCN FOR CHANGES | | 02/19/00 | | W.A.E. |
| C | REFER TO DCN FOR CHANGES | | 03/13/00 | | W.A.E. |
| D | REFER TO DCN FOR CHANGES | | 05/15/00 | | W.A.E. |
| E | REFER TO DCN FOR CHANGES | | 07/07/00 | | W.A.E. |
| F | REFER TO DCN FOR CHANGES | | 08/21/00 | | W.A.E. |
| G | REFER TO DCN FOR CHANGES | | 11/10/00 | | W.A.E. |
| H | REFER TO DCN FOR CHANGES | | 12/11/00 | | W.A.E. |
| I | REFER TO DCN FOR CHANGES | | 02/23/01 | | W.A.E. |
| J | REFER TO DCN FOR CHANGES | | 05/23/01 | | W.A.E. |
| K | REFER TO DCN FOR CHANGES | | 01/07/03 | J.T.S. | W.A.E. |
| L | REFER TO DCN FOR CHANGES | | 10/12/06 | J.T.S. | W.A.E. |
| M | REFER TO DCN FOR CHANGES | | 11/17/08 | J.T.S. | W.A.E. |
| N | REFER TO DCN FOR CHANGES | | 02/25/09 | J.T.S. | W.A.E. |
| O | REFER TO DCN FOR CHANGES | | 06/07/10 | J.T.S. | W.A.E. |
| P | REFER TO DCN FOR CHANGES | | 07/27/11 | J.T.S. | W.A.E. |
| Q | REFER TO DCN FOR CHANGES | | 02/21/12 | J.T.S. | W.A.E. |
| R | REFER TO DCN FOR CHANGES | | 01/30/14 | J.T.S. | W.A.E. |
| S | REFER TO DCN FOR CHANGES | | 05/25/14 | J.T.S. | W.A.E. |
| T | REFER TO DCN FOR CHANGES | | 09/01/16 | K.S.W. | W.A.E. |

EXAMPLE KIT IDENTIFICATION



THE MASTER DRAWING LIST COVERS THE BASIC INSTALLATION AND ALL OPTIONS REFER TO SHT. 4 FOR APPLICABLE DRAWINGS FOR SELECTED OPTIONS.

| DRAWING | SHEET NO. | TITLE | DATE | REVISION / DATE | A/C CONFIGURATION | | | |
|-------------|-----------|---|----------|-----------------|------------------------------|-----------------------|---------------------------------|---|
| | | | | | LOCKHEED L-1011-385-1 SERIES | LOCKHEED L-1011-385-3 | LOCKHEED L-1011-385-1 FREIGHTER | LOCKHEED L-1011-385-1 FREIGHTER W/ SMALL C1 COMPARTMENT |
| TFC07-0054G | 3 | CLASS D CARGO COMP. FPS ENCLOSURE / FIREX PLATE LOCATION INSTRUCTIONS | 08/20/99 | A-12/06/99 | | X | | |
| TFC07-0054G | 4 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 08/20/99 | A-12/06/99 | | X | | |
| TFC07-0054G | 5 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054G | 6 | CLASS D CARGO COMP. FPS ENCLOSURE / FIREX PLATE LOCATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054G | 7 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054G | 8 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054G | 9 | CLASS D CARGO COMP. FPS ENCLOSURE / FIREX PLATE LOCATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054G | 10 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054G | 11 | CLASS D CARGO COMP. FPS ENCLOSURE / FIREX PLATE LOCATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054G | 12 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054G | 13 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054G | 14 | CLASS D CARGO COMP. FPS ENCLOSURE / FIREX PLATE LOCATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054G | 15 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054G | 16 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054G | 17 | CLASS D CARGO COMP. FPS ENCLOSURE / FIREX PLATE LOCATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054G | 18 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |

TABLE 1

| A/C CONFIGURATION | APPLICABLE MODELS |
|-------------------|--|
| -100 | L-1011-385-1 AIRCRAFT |
| -200 | L-1011-385-3 AIRCRAFT |
| -300 | L-1011-385-1 AIRCRAFT (DETECTION ONLY) |
| -400 | L-1011-385-1 AIRCRAFT (DETECTION ONLY W/ SMALL C1 CARGO COMPARTMENT) |

NOTES:

- 1. FOR LOCKHEED L1011, HZ-HM5 AIRCRAFT REFER TO MASTER DRAWING LIST, TFA10-0055A-HM5.
- 2. FOR LOCKHEED L1011, HZ-HM6 AIRCRAFT REFER TO MASTER DRAWING LIST, TFA10-0055A-HM6.
- 3. COMPLY WITH AAE, LTD. SERVICE LETTER 26-6 FOR EACH CARGO FPS INSTALLATION.

UNLESS OTHERWISE SPECIFIED
 DRAWN IN AUTOCAD:
 SCALE: NONE
 PRINTED NOT TO SCALE
 TOLERANCES ON:
 DECIMALS
 3 PLACE ± .015
 2 PLACE ± .03
 1 PLACE ± .10
 FRACTIONS ± 1/32
 HOLE TOLERANCE ±10% DIA.
 SURFACE ROUGHNESS PER ANSI-B-46.1
 MACHINE SURFACE FINISH
 DIMENSIONING & TOLERANCING PER ANSI-Y-14.5
 CONCENTRICITY BETWEEN ANY DIA(S) ON THE SAME CENTER LINE SHALL NOT EXCEED .010 TOTAL INDICATOR READING.
 ALL DIM. IN INCHES & INCLUDE APPLIED FINISH.
 WELD SYMBOLS PER ANSI-Y-32.3
 RIVET CODE PER NAS 523
 THREADS PER MIL-S-7742
 MARK PER MIL-STD-130
 REMOVE ALL BURRS AND SHARP EDGES
 INTERPRET IN ACCORDANCE WITH DOD-STD-100

THIS DOCUMENT IS THE PROPERTY OF ADVANCED AIRCRAFT EXTINGUISHERS, LTD. (AAE, LTD). YOU MAY NOT POSSESS, USE, COPY, OR DISCLOSE THIS DOCUMENT OR AN INFORMATION IN IT, FOR ANY PURPOSE, INCLUDING WITHOUT LIMITATION TO DESIGN, MANUFACTURE, OR REPAIR PARTS, OR OBTAIN FAA OR OTHER GOVERNMENT APPROVAL TO DO SO, WITHOUT AAE'S EXPRESS WRITTEN PERMISSION. NEITHER RECEIPT NOR POSSESSION OF THIS DOCUMENT ALONE, FROM ANY SOURCE, CONSTITUTES SUCH PERMISSION. POSSESSION, USE, COPYING, OR DISCLOSING BY ANYONE WITHOUT AAE'S EXPRESS WRITTEN PERMISSION IS NOT AUTHORIZED AND MAY RESULT IN CRIMINAL AND/OR CIVIL LIABILITY. THIS DOCUMENT REMAINS PROPERTY OF AAE, LTD. THIS DOCUMENT IS NOT RELEASABLE UNDER THE FREEDOM OF INFORMATION ACT. COPYRIGHT AAE, LTD.

A.A.E., LTD. P.O. BOX 1117
 BLUE SPRINGS, MO 64013
 PHONE: (816)228-3322

DRAWING LIST

| | | | | |
|----------|------------------|----------|--------------|------------------------|
| APPD. | W.A. ENK | 08/20/99 | DWG. NO.: | TFA10-0055 |
| ENGR. | J.T. SUMMERVILLE | 08/20/99 | MODEL: | LOCKHEED L-1011 SERIES |
| CKD. BY | W.D. WHITE | 09/01/16 | EFFECTIVITY: | AS SHOWN |
| DRAWN BY | J.T. SUMMERVILLE | 08/20/99 | FILE NO. | 1000551 |
| | | | SHEET: | 1 of 4 |
| | | | REV: | T |

DATE: 08/20/99 TIME: 00:00

| DRAWING | SHEET NO. | TITLE | DATE | REVISION / DATE | A/C CONFIGURATION | | | |
|-------------|-----------|--|----------|-----------------|------------------------------|-----------------------|---------------------------------|---|
| | | | | | -100 | -200 | -300 | -400 |
| | | | | | 1 | 2 | 3 | 4 |
| | | | | | LOCKHEED L-1011-385-1 SERIES | LOCKHEED L-1011-385-3 | LOCKHEED L-1011-385-1 FREIGHTER | LOCKHEED L-1011-385-1 FREIGHTER W/ SMALL CI COMPARTMENT |
| TFC07-0054H | 1 | CLASS D CARGO COMP. FPS FIREX PLATE INSTALL. INSTRUCTIONS | 08/20/99 | B-01/18/01 | X | X | | |
| TFC07-0054H | 2 | CLASS D CARGO COMP. FPS FIREX PLATE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054H | 3 | CLASS D CARGO COMP. FPS FIREX PLATE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054H | 4 | CLASS D CARGO COMP. FPS FIREX PLATE INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054H | 5 | CLASS D CARGO COMP. FPS FIREX PLATE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054H | 6 | CLASS D CARGO COMP. FPS FIREX PLATE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054H | 7 | CLASS D CARGO COMP. FPS FIREX PLATE INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054J | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC07-0054K | 1 | CLASS D CARGO COMP. FPS TUBING/WIRING CLAMPING INSTALLATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054K | 2 | CLASS D CARGO COMP. FPS TUBING/WIRING CLAMPING INSTALLATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054K | 3 | CLASS D CARGO COMP. FPS TUBING/WIRING CLAMPING INSTALLATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054K | 4 | CLASS D CARGO COMP. FPS TUBING/WIRING CLAMPING INSTALLATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054L | 1 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 08/20/99 | A-02/15/00 | | X | | |
| TFC07-0054L | 2 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 08/20/99 | B-03/13/00 | | X | | |
| TFC07-0054L | 3 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 08/20/99 | B-03/13/00 | | X | | |
| TFC07-0054L | 4 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054L | 5 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054L | 6 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 02/15/00 | A-03/13/00 | X | | | |
| TFC07-0054L | 7 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 02/15/00 | A-03/13/00 | X | | | |
| TFC07-0054L | 8 | CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL. INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054M | 1 | CLASS D CARGO COMP. FPS WIRING LAYOUT | 08/20/99 | A-12/06/99 | | X | | |
| TFC07-0054M | 2 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054M | 3 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 08/20/99 | A-12/06/99 | | X | | |
| TFC07-0054M | 4 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054M | 5 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054M | 6 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054M | 7 | CLASS D CARGO COMP. FPS WIRING LAYOUT | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054M | 8 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054M | 9 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054M | 10 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054M | 11 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054M | 12 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054N | 1 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING INSTRUCTIONS | 08/20/99 | C-05/15/00 | X | X | | |
| TFC07-0054N | 2 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING INSTRUCTIONS | 08/20/99 | B-03/13/00 | X | X | | |
| TFC07-0054N | 3 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING INSTRUCTIONS | 08/20/99 | A-03/13/00 | X | X | | |
| TFC07-0054N | 4 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 08/20/99 | A-02/15/00 | | X | | |
| TFC07-0054N | 5 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 08/20/99 | A-02/15/00 | | X | | |
| TFC07-0054N | 6 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 08/20/99 | A-02/15/00 | | X | | |
| TFC07-0054N | 7 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 08/20/99 | A-02/15/00 | | X | | |
| TFC07-0054N | 8 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054N | 9 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054N | 10 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054N | 11 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054N | 12 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 02/15/00 | A-03/13/00 | X | | | |
| TFC07-0054N | 13 | CLASS D CARGO COMP. FPS SUPPRESSION TUBING ROUTING INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054P | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC07-0054Q | 1 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | X | X | | |
| TFC07-0054Q | 2 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 08/20/99 | A-12/06/99 | | X | | |
| TFC07-0054Q | 3 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 08/20/99 | A-12/06/99 | | X | | |
| TFC07-0054Q | 4 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054Q | 5 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 08/20/99 | IR-08/20/99 | | X | | |
| TFC07-0054Q | 6 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054Q | 7 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054Q | 8 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 02/15/00 | IR-02/15/00 | X | | | |
| TFC07-0054Q | 9 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 02/15/00 | A-11/10/00 | X | | | |
| TFC07-0063 | 1-2 | CLASS C CARGO COMP. FPS BILL OF MATERIALS | 11/01/00 | C-10/12/06 | | X | X | |
| TFC07-0063A | 1 | CLASS D CARGO COMP. FPS ENCLOSURE LAYOUT | 11/01/00 | A-01/18/01 | | X | | |
| TFC07-0063A | 2 | CLASS D CARGO COMP. FPS ENCLOSURE LAYOUT | 12/29/00 | IR-12/29/00 | | | X | |
| TFC07-0063B | 1 | CLASS D CARGO COMP. FPS CONTROL PANEL LOCATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | X | X | |
| TFC07-0063C | 1 | CLASS D CARGO COMP. FPS CIR. BREAKER LOCATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | X | X | |
| TFC07-0063D | 1 | CLASS D CARGO COMP. FPS ANNUNCIATOR LOCATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | X | X | |
| TFC07-0063E | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | X | X | |
| TFC07-0063F | 1 | CLASS D CARGO COMP. FPS FAULT PANEL INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | X | | |
| TFC07-0063F | 2 | CLASS D CARGO COMP. FPS FAULT PANEL INSTALL. INSTRUCTIONS | 12/29/00 | IR-12/29/00 | | | X | |

| DRAWING | SHEET NO. | TITLE | DATE | REVISION / DATE | A/C CONFIGURATION | | | |
|-------------|-----------|---|----------|-----------------|------------------------------|-----------------------|---------------------------------|---|
| | | | | | -100 | -200 | -300 | -400 |
| | | | | | 1 | 2 | 3 | 4 |
| | | | | | LOCKHEED L-1011-385-1 SERIES | LOCKHEED L-1011-385-3 | LOCKHEED L-1011-385-1 FREIGHTER | LOCKHEED L-1011-385-1 FREIGHTER W/ SMALL CI COMPARTMENT |
| TFC07-0063G | 1 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 2 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 3 | CLASS D CARGO COMP. FPS ENCLOSURE LOCATION INSTRUCTIONS | 11/01/00 | A-01/18/01 | | | X | |
| TFC07-0063G | 4 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 5 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | |
| TFC07-0063G | 6 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | A-01/18/01 | | | X | |
| TFC07-0063G | 7 | CLASS D CARGO COMP. FPS ENCLOSURE LOCATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 8 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 9 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 10 | CLASS D CARGO COMP. FPS ENCLOSURE LOCATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 11 | CLASS D CARGO COMP. FPS ENCLOSURE INSTALL. INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063G | 12 | CLASS D CARGO COMP. FPS ENCLOSURE LOCATION INSTRUCTIONS | 12/29/00 | IR-12/29/00 | | | | X |
| TFC07-0063H | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063J | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063K | 1 | CLASS D CARGO COMP. FPS WIRING CLAMPING INSTALLATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063L | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063M | 1 | CLASS D CARGO COMP. FPS WIRING LAYOUT | 11/01/00 | A-01/18/01 | | | X | |
| TFC07-0063M | 2 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 11/01/00 | A-12/29/00 | | | X | X |
| TFC07-0063M | 3 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 11/01/00 | A-01/18/01 | | | X | |
| TFC07-0063M | 4 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 11/01/00 | A-12/29/00 | | | X | X |
| TFC07-0063M | 5 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063M | 6 | CLASS D CARGO COMP. FPS WIRING LAYOUT | 12/29/00 | IR-12/29/00 | | | | X |
| TFC07-0063M | 7 | CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS | 12/29/00 | IR-12/29/00 | | | | X |
| TFC07-0063N | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063P | 1 | CLASS D CARGO COMP. FPS INSTALLATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | X |
| TFC07-0063Q | 1 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 11/01/00 | IR-11/01/00 | | | X | |
| TFC07-0063Q | 2 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 11/01/00 | A-01/18/01 | | | X | |
| TFC07-0063Q | 3 | CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS | 11/01/00 | A-12/29/00 | | | X | |

NOTES:
SEE SHEET 1

SEE SHEET 1 FOR REVISION DESCRIPTION

A.A.E., LTD. P.O. BOX 1117
BLUE SPRINGS, MO 64013
PHONE: (816)228-3322

TITLE: DRAWING LIST

DWG. NO.: TFA10-0055

MODEL: LOCKHEED L-1011 SERIES

EFFECTIVITY: AS SHOWN
FILE NO. 1000552
SHEET: 2 of 4 REV: T

DATE: 01/07/03 TIME: 00:00

| DRAWING | SHEET NO. | TITLE | DATE | REVISION / DATE | A/C CONFIGURATION | | | |
|--------------------|-----------|--|----------|-----------------|------------------------------|-----------------------|---------------------------------|---|
| | | | | | LOCKHEED L-1011-385-1 SERIES | LOCKHEED L-1011-385-3 | LOCKHEED L-1011-385-1 FREIGHTER | LOCKHEED L-1011-385-1 FREIGHTER W/ SMALL C1 COMPARTMENT |
| TFA09-0045 | | AIRPLANE FLIGHT MANUAL SUPPLEMENT | 03/00 | A-02/01 | X | X | | |
| TFA09-0055 | | AIRPLANE FLIGHT MANUAL SUPPLEMENT | 02/01 | IR-02/01 | | | X | X |
| TFA11-0005 | 1 | ELIGIBILITY LIST | 08/20/99 | A-02/15/00 | X | X | X | X |
| TFC12-0056-() | 1 | FAULT PANEL ASSEMBLY | 03/98 | H-11/19/01 | X | X | | |
| TFC12-0056-() | 2 | FAULT PANEL ASSEMBLY | 06/98 | F-11/19/01 | X | X | | |
| TFC12-0056-() | 3 | FAULT PANEL ASSEMBLY | 06/98 | E-12/05/00 | X | X | | |
| TFC12-0056-() | 4 | FAULT PANEL ASSEMBLY | 06/98 | D-11/19/01 | X | X | | |
| TFC12-0062 | 1 | SPECIFICATION CONTROL DWG. FAULT PANEL ASSEMBLY | 12/06/99 | A-02/15/00 | X | X | | |
| TFC12-0063-() | 1 | SPEC. CONTROL DWG. DETECTION/SUPPRESSION CONTROL PANEL | 12/06/99 | A-02/18/09 | X | X | X | X |
| TFC12-0069-() | 1 | FAULT PANEL ASSEMBLY | 11/01/00 | A-12/29/00 | | | X | X |
| TFC12-0069-() | 2 | FAULT PANEL ASSEMBLY | 11/01/00 | A-12/29/00 | | | X | X |
| TFC12-0069-() | 3 | FAULT PANEL ASSEMBLY | 11/01/00 | A-12/29/00 | | | X | X |
| TFC12-0069-() | 4 | FAULT PANEL ASSEMBLY | 11/01/00 | A-12/29/00 | | | X | X |
| TFC12-0070 | 1 | SPECIFICATION CONTROL DWG. FAULT PANEL ASSEMBLY | 11/01/00 | A-12/29/00 | | | X | |
| TFC12-0071-() | 1 | SPECIFICATION CONTROL DWG. DETECTION CONTROL PANEL | 11/01/00 | A-02/18/09 | | | X | X |
| TFC12-0072 | 1 | SPECIFICATION CONTROL DWG. FAULT PANEL ASSEMBLY | 12/29/00 | IR-12/29/00 | | | | X |
| TFC13-0023-() | 1 | SPEC. CONTROL DWG. DETECTOR | 05/98 | F-02/11/09 | X | X | | |
| TFC13-0024-() | 1 | SPECIFICATION CONTROL DWG. DETECTOR | 07/07/00 | I-01/30/14 | | | X | X |
| TFC14-0040-() | 1 | SPECIFICATION CONTROL DWG. BOTTLE ASSEMBLY, EXTINGUISHER | 01/06/99 | C-04/06/16 | X | X | | |
| TFC14-0042-() | 1 | SPECIFICATION CONTROL DWG. BOTTLE ASSEMBLY, EXTINGUISHER | 08/20/99 | E-04/06/16 | X | X | | |
| TFC14-0043-() | 1 | SPECIFICATION CONTROL DWG. ORIFICE FILTER ASSEMBLY | 08/20/99 | B-04/06/16 | X | X | | |
| TFC14-0044-() | 1-2 | SPECIFICATION CONTROL DWG. PARTICULATE FILTER ASSEMBLY | 08/20/99 | D-04/06/16 | X | X | | |
| TFC14-0046-() | 1 | SPECIFICATION CONTROL DWG. FILTER, INLINE ASSY | 08/20/99 | B-04/06/16 | X | X | | |
| TFC14-0052-() | 1 | FITTING, PARTICULATE FILTER | 03/16/06 | IR-03/16/06 | X | X | | |
| TFC14-0053-() | 1 | PARTICULATE FILTER | 03/16/06 | IR-03/16/06 | X | X | | |
| TFC14-0054-() | 1-2 | PARTICULATE FILTER ASSEMBLY | 03/16/06 | A-11/01/07 | X | X | | |
| TFA15-0003-()-() | 1 | BULKHEAD NOZZLE | 02/79 | I-05/31/02 | X | X | | |
| TFC15-0016-() | 1 | SPECIFICATION CONTROL DWG. FIREX NOZZLE | 12/97 | I-04/06/16 | X | X | | |
| TFC15-0017-() | 1 | SUSTAINING NOZZLE | 06/01/11 | IR-06/01/11 | X | X | | |
| TFC16-0028-() | 1 | SPECIFICATION CONTROL DWG. DIVERTER VALVE ASSY, 3 OUTLET | 12/97 | F-04/06/16 | X | X | | |
| TFC16-0030-() | 1 | SPECIFICATION CONTROL DWG. TEMPERATURE COMPENSATED PRESSURE REGULATOR | 08/20/99 | A-04/06/16 | X | X | | |
| TFA17-0054 | | GROUND AND FLIGHT TEST PLAN | 01/99 | IR-01/99 | X | X | X | X |
| TFA17-0055 | | INSTRUMENTATION PLAN | 01/99 | A-01/00 | X | X | X | X |
| TFA17-0056 | | GROUND FUNCTIONAL TEST PLAN | 09/99 | IR-09/99 | X | X | X | X |
| TFA17-0057 | | FLIGHT TEST PLAN | 02/99 | B-01/00 | X | X | X | X |
| TFA17-0058 | | GROUND AND FLIGHT TEST PROCEDURE | 03/18/99 | IR-03/18/99 | X | X | X | X |
| TFA17-0059 | | FLIGHT TEST PLAN | 09/99 | IR-09/99 | X | X | X | X |
| TFA17-0060 | | SUPPLEMENTAL GROUND FUNCTIONAL TEST PLAN, L1011 | 12/99 | IR-12/99 | X | X | X | X |
| TFA17-0061 | | INSPECTION OF C3 CARGO COMPARTMENT INTERIOR, DOOR, AND FLOW TEST OF INLET AND OUTLET VALVES FOR L-1011-385-3 "C3 CARGO COMPARTMENT" VENTILATION SYSTEM | 02/00 | IR-02/00 | X | X | X | X |
| TFA18-0105 | | COMPLIANCE CHECKLIST | 12/98 | IR-12/98 | X | X | X | X |
| TFA18-0106 | | TEST REPORT CARGO FPS | 02/00 | IR-02/00 | X | X | X | X |
| TFA18-0107 | | BURN TEST SUBSTANTIATION REPORT | 10/99 | IR-10/99 | X | X | X | X |
| TFA18-0110 | | STRUCTURAL SUBSTANTIATION REPORT | 12/99 | IR-12/99 | X | X | X | X |
| TFA18-0111 | | FUNCTION AND TESTING OF THE AAE LTD. L1011 FPS AND ITS ELECTRONIC EQUIPMENT, AND INSTALLATION WITH TFC12-0063-() DETECTION/SUPPRESSION CONTROL HEAD TO SHOW COMPLIANCE WITH THE FAR'S | 03/00 | IR-03/00 | X | X | X | X |
| TFA18-0112 | | SAFETY ASSESSMENT REPORT | 02/00 | IR-02/00 | X | X | X | X |
| TFA18-0113 | | MAINTENANCE INSTRUCTIONS | 12/99 | A-04/01 | X | X | X | X |
| TFA18-0114 | | ELECTRICAL LOAD SUMMARY REPORT | 02/00 | IR-02/00 | X | X | X | X |
| TFA18-0115 | | COMPLIANCE SUMMARY REPORT | 03/00 | IR-03/00 | X | X | X | X |
| SL 26-6 | | LOADING OF CARGO COMPARTMENT TO INSURE PROPER FUNCTIONING OF THE AAE CARGO FIRE PROTECTION SYSTEM (FPS) | 05/01/14 | IR-05/01/14 | X | X | X | X |

NOTES:
SEE SHEET 1

SEE SHEET 1 FOR REVISION DESCRIPTION

A.A.E., LTD. P.O. BOX 1117
BLUE SPRINGS, MO 64013
PHONE: (816)228-3322

TITLE: DRAWING LIST

DWG. NO.: TFA10-0055

MODEL: LOCKHEED L-1011 SERIES

| | |
|--------------------------|----------------------|
| EFFECTIVITY: AS SHOWN | FILE NO. 1000553 |
| | SHEET: 3 of 4 REV: T |

DATE: 01/07/03 TIME: 00:00

KIT OPTION CODE

'A'
'E'
'H'
'T'

KIT OPTION IDENTIFICATION

AUTOFIRE CONTROL PANEL
FIRE EXTINGUISHER BOTTLES CONTAINING METHONAL
FLARED FITTINGS - SUPPRESSION TUBING
DETECTION ONLY

| KIT OPTIONS | DRAWINGS NOT APPLICABLE FOR THIS OPTION | DRAWING APPLICABLE FOR THIS OPTION |
|-------------|--|---|
| 'A' | | TFC03-0167-(101) SHT. 1 TFC03-0167-(102) SHT. 1 TFC03-0169 SHT. 1 TFC03-0170 SHT. 1 TFA09-0045 TFC12-0063-(1) SHT. 1 |
| 'E' | TFC14-0047-(1) SHT. 1 TFC04-0049-(1) SHT. 1 | TFC14-0039-(1) SHT. 1 TFC14-0047-(1) SHT. 1 |
| 'H' | NONE | ALL |
| 'T' | | TFC03-0214-(101) SHT. 1 TFC03-0214-(102) SHT. 1 TFC03-0218 SHT. 1 TFC03-0221 SHT. 1 TFA09-0055 TFC12-0071-(1) SHT. 1 |

KIT NUMBERS

- 1 TFK L-1011-385-1 (-100) 'A', 'E', AND 'H'
- 2 TFK L-1011-385-3 (-200) 'A', 'E', AND 'H'
- 3 TFK L-1011-385-1 (-300) 'T'
- 4 TFK L-1011-385-1 (-400) 'T'

SEE SHEET 1 FOR REVISION DESCRIPTION

A.A.E., LTD. P.O. BOX 1117
BLUE SPRINGS, MO 64013
PHONE: (816)228-3322

TITLE: DRAWING LIST

DWG. NO.: TFA10-0055

MODEL: LOCKHEED L-1011 SERIES

| | |
|--------------------------|----------------------|
| EFFECTIVITY: AS SHOWN | FILE NO. 1000554 |
| | SHEET: 4 of 4 REV: T |