

DATE: 03/02/98 TIME: 10:02

DRAWING	SHEET NO.	TITLE	DATE	REVISION / DATE	A/C CONFIGURATION					
					-100	-200	-300	-400	-500	-600
TFC03-0132-( )	1	SPECIFICATION CONTROL DWG. WIRE KIT, SMOKE DETECTION	5/98	G/8-11-03	X	X	X			X
TFC03-0134-( )	1	SPECIFICATION CONTROL DWG. HARNESS, SUPPRESSION	5/98	E/8-11-03	X	X	X			X
TFC03-0136	1	SPECIFICATION CONTROL DWG. SYSTEM DIAGRAM SMOKE DETECTION, NON-AUTOFIRE, B737	5/98	H/8-11-03	X	X	X			X
TFC03-0138	1	SPECIFICATION CONTROL DWG. SYSTEM DIAGRAM CARGO FIRE SUPPRESSION, NON-AUTOFIRE, B737	5/98	C/4-19-99	X	X	X			X
TFC03-0140	1	SPECIFICATION CONTROL DWG. WIRE LIST	5/98	E/8-11-03	X	X	X			X
TFC03-0144-( )	1	SPECIFICATION CONTROL DWG. HOUSING ASSEMBLY FIRE DETECTION, SYSTEM	6/98	B/5-03-00	X	X	X			X
TFC03-0146	1	SPECIFICATION CONTROL DWG. SPLICE LABEL FABRICATION / KIT	6/98	C/5-14-99	X	X	X	X	X	X
TFC03-0148	1	SPECIFICATION CONTROL DWG. HARNESS, ADF EXTENSION	6/98	B/6-17-99		X				
TFC03-0150	1	SPECIFICATION CONTROL DWG. WIRE LIST (ADF EXTENSION HARNESS)	6/98	A/10-16-98		X				
TFC03-0152-( )	1	SPECIFICATION CONTROL DWG. MASTER KIT, SMOKE DETECTION/SUPPRESSION	6/98	C/5-03-00	X	X	X			X
TFC03-0154-( )	1	SPECIFICATION CONTROL DWG. MASTER KIT, SMOKE DETECTION/SUPPRESSION	7/07/99	A/5-03-00	X	X	X			X
TFC03-0159	1	SPECIFICATION CONTROL DWG. FUEL FLOW PWR SUPPLY EXTENDER HARNESS	4/23/99	A/5-20-99	X					
TFC03-0198	1	SPECIFICATION CONTROL DWG. HARNESS KIT, CONTROL PANEL, AUTOFIRE	4/24/00	C/8-11-03	X	X	X			X
TFC03-0199	1	SPECIFICATION CONTROL DWG. SYSTEM DIAGRAM SMOKE DETECTION, AUTOFIRE, B737	5/03/00	C/8-11-03	X	X	X			X
TFC03-0200	1	SPECIFICATION CONTROL DWG. SYSTEM DIAGRAM CARGO FIRE SUPPRESSION, AUTOFIRE, B737	5/03/00	IR/5-03-00				X	X	X
TFC03-0203-( )	1	SPECIFICATION CONTROL DWG. SUPPLEMENTAL CONTROL PANEL RELOCATION KIT	7/14/00	IR/7-14-00	X	X	X	X	X	X
TFC03-0204-( )	1	SPECIFICATION CONTROL DWG. WIRE KIT, (OVHD CP)	7/14/00	IR/7-14-00	X	X	X	X	X	X
TFC03-0205-( )	1	SPECIFICATION CONTROL DWG. HARNESS KIT, CONTROL PANEL, AUTOFIRE (OVHD CP)	7/14/00	B/12-18-00	X	X	X	X	X	X
TFC03-0206-( )	1	SPECIFICATION CONTROL DWG. HARNESS, SUPPRESSION (OVHD CP)	7/14/00	IR/7-14-00	X	X	X	X	X	X
TFC03-0207-( )	1	SPECIFICATION CONTROL DWG. MASTER KIT, SMOKE DETECTION/SUPPRESSION	12/18/00	IR/12-18-00			X	X		
TFC03-0208-( )	1	SPECIFICATION CONTROL DWG. WIRE KIT, SMOKE DETECTION, AUTOFIRE	12/18/00	B/8-11-03	X	X	X			
TFC03-0209-( )	1	SPECIFICATION CONTROL DWG. WIRE KIT, SUPPRESSION, AUTOFIRE	12/18/00	A/12-13-01			X	X		
TFC03-0210-( )	1	SPECIFICATION CONTROL DWG. HOUSING ASSEMBLY FIRE DETECTION, SYSTEM	12/18/00	IR/12-18-00			X	X		
TFC03-0211	1	SPECIFICATION CONTROL DWG. WIRE LIST	12/18/00	A/8-11-03			X	X		
TFC03-0212-( )	1-2	EXTENSION HARNESS KIT, CARGO FIRE SUPPRESSION, NON-AUTOFIRE	9/23/00	IR/9-23-00	X					
TFC03-0213	1	SPECIFICATION CONTROL DWG. SYSTEM DIAGRAM SMOKE DETECTION, AUTOFIRE, B737	12/18/00	B/8-11-03			X	X		
TFC03-0223-( )	1-2	EXTENSION HARNESS KIT, CARGO FIRE SUPPRESSION, AUTOFIRE	2/23/01	IR/2-21-01	X					
TFC03-0242-( )	1	SPECIFICATION CONTROL DWG., 5 CONDUCTOR COMPOSITE CABLE	3/17/03	IR/3-17-03	X	X	X	X	X	X
TFC03-0243-( )	1-2	HARNESS KIT, SMOKE DETECTION	4/01/03	A/2-07-05	X	X	X			X
TFC03-0244-( )	1	HARNESS KIT, DETECTOR ENCLOSURE	4/01/03	C/2-07-05	X	X	X	X	X	X
TFC03-0245-( )	1-2	HARNESS KIT, CONTROL PANEL	4/01/03	IR/4-01-03	X	X	X	X	X	X
TFC03-0246-( )	1-2	HARNESS KIT, FIRE SUPPRESSION	4/01/03	A/2-07-05	X	X	X			X
TFC03-0247-( )	1-2	HARNESS KIT, INTERFACE TRAY ASSEMBLY	4/01/03	B/2-07-05	X	X	X	X	X	X
TFC03-0248-( )	1-2	ENCLOSURE / WIRE HARNESS ASSEMBLY	4/01/03	IR/4-01-03	X	X	X	X	X	X
TFC03-0249-( )	1	MASTER KIT, SMOKE DETECTION/SUPPRESSION	4/01/03	A/2-07-05	X	X	X			X
TFC03-0250	1-9	B737 WIRE LIST (ML-W-22759)	2/11/03	B/12-05-14	X	X	X			X
TFC03-0251	1-7	SYSTEM DIAGRAM, SMOKE DETECTION, B737	4/01/03	B/12-05-14	X	X	X			X
TFC03-0252	1	SYSTEM DIAGRAM, FIRE SUPPRESSION, B737	4/01/03	IR/4-01-03	X	X	X	X	X	X
TFC03-0253	1-9	B737 WIRE LIST (BMS13-60)	4/01/03	B/12-05-14	X	X	X			X
TFC03-0254-( )	1-2	HARNESS KIT, SMOKE DETECTION	4/01/03	A/2-07-05			X	X		
TFC03-0255-( )	1-2	HARNESS KIT, FIRE SUPPRESSION	4/01/03	A/2-07-05			X	X		
TFC03-0256-( )	1	MASTER KIT, SMOKE DETECTION/SUPPRESSION	4/01/03	A/2-07-05			X	X		
TFC03-0257	1-7	SYSTEM DIAGRAM, SMOKE DETECTION, B737	4/01/03	B/12-09-12			X	X		
TFC03-0258	1-10	B737 WIRE LIST (ML-W-22759)	4/01/03	A/9-06-04			X	X		
TFC03-0259	1-10	B737 WIRE LIST (BMS13-60)	4/01/03	A/9-06-04			X	X		
TFC03-0309-( )	1-2	HARNESS KIT, CONTROL PANEL	2/07/05	IR/2-07-05	X	X	X	X	X	X
TFC03-0310	1-9	B737 WIRE LIST (ML-W-22759)	2/07/05	IR/2-07-05	X	X	X			X
TFC03-0311	1-9	B737 WIRE LIST (BMS13-60)	2/07/05	IR/2-07-05	X	X	X			X
TFC03-0312	1-10	B737 WIRE LIST (ML-W-22759)	2/07/05	IR/2-07-05			X	X		
TFC03-0313	1-10	B737 WIRE LIST (BMS13-60)	2/07/05	IR/2-07-05			X	X		
TFC03-0314	1-7	SYSTEM DIAGRAM, SMOKE DETECTION, B737	2/07/05	IR/2-07-05	X	X	X			X
TFC03-0315	1	SYSTEM DIAGRAM, FIRE SUPPRESSION, B737	2/07/05	IR/2-07-05	X	X	X	X	X	X
TFC03-0316	1-7	SYSTEM DIAGRAM, SMOKE DETECTION, B737	2/07/05	IR/2-07-05	X	X	X	X	X	X
TFC04-0049-( )	1	SPECIFICATION CONTROL DWG. METERING VALVE TUBING ASSEMBLY	9/97	H-04/06/16		X	X			X
TFC04-0052-( )	1	SPECIFICATION CONTROL DWG. DIVERTER VALVE TUBING ASSEMBLY	9/97	H-04/06/16		X	X			X
TFC04-0053-( )	1	SPECIFICATION CONTROL DWG. TUBING ASSEMBLY, FORMED	5/98	D-04/06/16		X	X			X
TFC04-0054-( )	1	SPECIFICATION CONTROL DWG. TUBING ASSEMBLY, FORMED	5/98	D-04/06/16		X				X
TFC04-0055-( )	1	SPECIFICATION CONTROL DWG. BOTTLE 2 TUBING ASSEMBLY	9/01/99	C/4-06-05			X			
TFC05-0037-( )	1-2	FAULT BOX	7/97	I/11-08-02	X	X	X	X	X	X
TFC05-0039-( )	1,3,5	LABEL	5/98	A/9-24-98	X	X	X	X	X	X
TFC05-0042	1-2	FAULT PLATE	3/98	A/10-13-98	X	X	X			X
TFC05-0044-( )	1-2	PLACARDS	6/98	C/12-18-00	X	X	X	X	X	X
TFC05-0059	1-2	FAULT PLATE	12/18/00	IR/12-18-00			X	X		
TFC05-0068-( )	1	PLACARDS	2/11/03	IR/2-11-03	X	X	X	X	X	X
TFC05-0072	1	LABEL	5/25/14	IR/5-25-14	X	X	X	X	X	X
TFC05-0073	1	LABEL	5/25/14	IR/5-25-14	X	X	X	X	X	X
TFC06-0043-( )	2	MOUNTING PLATE ASSEMBLY, SUPPRESSION	5/98	A/10-13-98		X	X			X
TFC06-0044-( )	2	MOUNTING PLATE ASSEMBLY, SUPPRESSION	5/98	A/10-13-98		X	X			X
TFC06-0045	1	SPECIFICATION CONTROL DWG., STRAP ASSEMBLY, RETAINING	9/97	C/03-03-16	X	X	X	X	X	X
TFC06-0051-( )	1	SPECIFICATION CONTROL DWG. ASSEMBLY FIRE DETECTION SYSTEM HOUSING	2/98	H/12-07-00	X	X	X	X	X	X
TFC06-0054-( )	1	GUARD BAR ASSEMBLY	1/98	F/5-25-14			X	X		X
TFC06-0055-( )	2	GUARD BAR ASSEMBLY	11/4/98	C/5-25-14	X	X	X	X	X	X
TFC06-0055	1	CLIP	7/98	A/10-28-98	X					
TFC06-0057-( )	1	VERTICAL CHANNEL	5/98	A/10-16-98		X	X			X
TFC06-0058-( )	1	UPPER SUPPORT ASSY, SUPPRESSION	5/98	B/10-16-98		X	X			X
TFC06-0059-( )	1	LOWER SUPPORT ASSY, SUPPRESSION	5/98	C/10-16-98		X	X			X
TFC06-0060-( )	1	SIDE SUPPORT ASSY, SUPPRESSION	5/98	C/10-13-98		X	X			X
TFC06-0060-( )	2	SIDE SUPPORT ASSY, SUPPRESSION	5/98	B/10-16-98		X	X			X
TFC06-0061	1	SHIM, LOWER SUPPORT	5/98	B/10-16-98		X	X			X
TFC06-0063-( )	1	MOUNTING PLATE, FIREX NOZZLE	5/98	C/5-06-02	X	X	X	X	X	X
TFC06-0065	1	SHIM, METERING VALVE	5/98	B/10-13-98		X	X			X

EXAMPLE KIT IDENTIFICATION



THE MASTER DRAWING LIST COVERS THE BASIC INSTALLATION AND ALL OPTIONS REFER TO SHT. 4 FOR APPLICABLE DRAWINGS FOR SELECTED OPTIONS.

TABLE 1

A/C CONFIGURATION	APPLICABLE MODELS
-100	B737-200 AIRCRAFT (STANDARD CONFIGURATION)
-200	B737-300 AIRCRAFT (STANDARD CONFIGURATION)
-300	B737-300 AIRCRAFT (EXTENDED RANGE CONFIGURATION)
-400	B737-400 AIRCRAFT (STANDARD CONFIGURATION)
-500	B737-400 AIRCRAFT (EXTENDED RANGE CONFIGURATION)
-600	B737-500 AIRCRAFT (STANDARD CONFIGURATION)

NOTES:

- 1. TO BE USED IN CONJUNCTION WITH DETECTION/SUPPRESSION MASTER KITS TFC03-0152-( ) AND TFC03-0154-( ).
- 2. TO BE USED IN CONJUNCTION WITH DETECTION/SUPPRESSION MASTER KIT TFC03-0207-( ).
- 3. TO BE USED IN CONJUNCTION WITH DETECTION/SUPPRESSION MASTER KITS TFC03-0152-( ), TFC03-0154-( ), AND TFC03-0207-( ).
- 4. TO BE USED IN CONJUNCTION WITH DETECTION/SUPPRESSION MASTER KIT TFC03-0249-( ).
- 5. TO BE USED IN CONJUNCTION WITH DETECTION/SUPPRESSION MASTER KIT TFC03-0256-( ).
- 6. TO BE USED IN CONJUNCTION WITH DETECTION/SUPPRESSION MASTER KITS TFC03-0249-( ) AND TFC03-0256-( ).
- 7. COMPLY WITH AAE, LTD. SERVICE LETTER 28-6 FOR EACH CARGO FPS INSTALLATION.

OUTSTANDING ECN'S	
ECN NUMBER	ECN NUMBER

REV	DESCRIPTION	REVISIONS				REVISED BY	APPROVED BY
		ECN	DATE				
A	INCORPORATED ECN	U73751498-2	7/1/98				
B	INCORPORATED ECN's	U73771498-126	10/19/98				W.A.E.
		U73771498-127					
		U73782898-167					
		U73791498-221					
C	INCORPORATED ECN's	U737111198-254	1/11/98				W.A.E.
D	REFER TO DCN FOR CHANGES		11/18/98				W.A.E.
E	INCORPORATED ECN's	U737011599-252	01/15/99				W.A.E.
F	INCORPORATED ECN's	U737021799-295	02/17/99				W.A.E.
G	REFER TO DCN FOR CHANGES		05/21/99				W.A.E.
H	REFER TO DCN FOR CHANGES		06/04/99				W.A.E.
I	REFER TO DCN FOR CHANGES		06/17/99				W.A.E.
J	REFER TO DCN FOR CHANGES		07/20/99				W.A.E.
K	REFER TO DCN FOR CHANGES		09/24/99				W.A.E.
L	REFER TO DCN FOR CHANGES		10/18/99				W.A.E.
M	REFER TO DCN FOR CHANGES		12/06/99				W.A.E.
N	REFER TO DCN FOR CHANGES		02/11/00				W.A.E.
Q	REFER TO DCN FOR CHANGES		05/03/00				W.A.E.
P	REFER TO DCN FOR CHANGES		07/14/00				W.A.E.
Q	REFER TO DCN FOR CHANGES		10/16/00				W.A.E.
R	REFER TO DCN FOR CHANGES		01/26/01				W.A.E.
S	REFER TO DCN FOR CHANGES		03/05/01				W.A.E.
T	REFER TO DCN FOR CHANGES		05/23/01				W.A.E.
U	REFER TO DCN FOR CHANGES		12/13/01				W.A.E.
V	REFER TO DCN FOR CHANGES		06/24/02				W.A.E.
W	REFER TO DCN FOR CHANGES		12/11/02		J.T.S.		W.A.E.
X	REFER TO DCN FOR CHANGES		04/01/03		J.T.S.		W.A.E.
Y	REFER TO DCN FOR CHANGES		08/11/03		J.T.S.		W.A.E.
Z	REFER TO DCN FOR CHANGES		11/10/03		J.T.S.		

DRAWING	SHEET NO.	TITLE	DATE	REVISION / DATE	A/C CONFIGURATION					
					BOEING 737 200 SERIES	BOEING 737 300 SERIES	BOEING 737 300 ER SERIES	BOEING 737 400 SERIES	BOEING 737 400 ER SERIES	BOEING 737 500 SERIES
TFC06-0112	1	ENCLOSURE SUPPORT ANGLE	2/15/00	IR/2-15-00	X					
TFC06-0126-( )	1-4	HOUSING ASSEMBLY, FIRE DETECTION SYSTEM	2/06/02	A/4-11-02	X	X	X	X	X	X
TFC06-0127-( )	1	SUPPRESSION RACK MOUNTING PLATE ASSEMBLY	10/23/01	IR/10-23-01				X		
TFC06-0128-( )	1	SUPPRESSION RACK SUPPORT CHANNEL ASSEMBLY	10/23/01	A/12-04-01				X	X	
TFC06-0128-( )	2	SUPPRESSION RACK SUPPORT CHANNEL ASSEMBLY	10/23/01	A/12-04-01				X	X	
TFC06-0129	1	SUPPRESSION RACK SIDE FLANGE	10/23/01	A/4-11-02				X	X	
TFC06-0130-( )	1	SUPPRESSION RACK MOUNTING PLATE ASSEMBLY	10/23/01	IR/10-23-01				X	X	
TFC06-0145-( )	1-2	TERMINAL BLOCK BRACKET ASSEMBLY	2/11/03	B-04/06/16	X	X	X	X	X	X
TFC06-0146-( )	1-2	RACK ASSEMBLY	2/11/03	IR/2-11-03	X	X	X	X	X	X
TFC06-0147-( )	1-3	ELECTRONIC INTERFACE TRAY ASSEMBLY	4/01/03	IR/4-01-03	X	X	X	X	X	X
TFC07-0043	1-10	CLASS C CARGO COMP. FPS BILL OF MATERIALS	5/98	V/7-27-11	X	X	X	X	X	X
TFC07-0043A	1	CLASS C CARGO COMP. FPS ENCLOSURE/FIREX PLATE LAYOUT	1/06/99	D/2-01-10	X					
TFC07-0043A	2	CLASS C CARGO COMP. FPS ENCLOSURE/FIREX PLATE LAYOUT	5/98	F/2-01-10		X				
TFC07-0043A	3	CLASS C CARGO COMP. FPS ENCLOSURE/FIREX PLATE LAYOUT	8/98	E/2-01-10						X
TFC07-0043A	4	CLASS C CARGO COMP. FPS ENCLOSURE/FIREX PLATE LAYOUT	9/01/99	C/10-20-10			X			
TFC07-0043B	1	CLASS C CARGO COMP. FPS CONTROL PANEL LOCATION INSTRUCTIONS	1/06/99	G/9-05-05	X	X	X			
TFC07-0043B	2	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	H/9-05-05		X	X			X
TFC07-0043C	1	CLASS D CARGO COMP. FPS CIR. BREAKER LOCATION INSTRUCTIONS	1/06/99	B/1-15-00	X					
TFC07-0043C	2	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	D/1-15-00		X	X			X
TFC07-0043C	3	CLASS D CARGO COMP. FPS CIR. BREAKER LOCATION INSTRUCTIONS	4/23/99	B/1-15-00		X	X			X
TFC07-0043D	2	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	A/10-13-98	X	X	X			X
TFC07-0043E	2	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	A/10-16-98	X	X	X			X
TFC07-0043F	3	CLASS D CARGO COMP. FPS FAULT PANEL INSTALL INSTRUCTIONS	5/98	I/12-04-01	X	X	X			X
TFC07-0043G	1	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	H/9-05-05	X	X	X			X
TFC07-0043G	1a	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	7/12/99	B/9-05-05	X	X	X			X
TFC07-0043G	2	CLASS D CARGO COMP. FPS ENCL./FIREX PAN LOCATION INSTRUCTIONS	1/06/99	B/7-05-99	X					
TFC07-0043G	3	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	1/06/99	D/4-01-03	X					
TFC07-0043G	4	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	1/06/99	C/4-01-03	X					
TFC07-0043G	5	CLASS D CARGO COMP. FPS ENCL./FIREX PAN LOCATION INSTRUCTIONS	5/98	D/9-01-99		X	X			
TFC07-0043G	6	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	5/98	C/4-01-03		X	X			
TFC07-0043G	7	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	5/98	E/4-01-03		X	X			
TFC07-0043G	8	CLASS D CARGO COMP. FPS ENCL./FIREX PAN LOCATION INSTRUCTIONS	8/98	C/7-14-00						X
TFC07-0043G	9	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	8/98	D/4-01-03						X
TFC07-0043G	10	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	8/98	B/4-01-03						X
TFC07-0043H	1	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	D/12-18-00	X	X	X			X
TFC07-0043H	3	CLASS D CARGO COMP. FPS FIREX PAN INSTALL INSTRUCTIONS	1/06/99	B/12-18-00	X					
TFC07-0043H	4	CLASS D CARGO COMP. FPS FIREX PAN INSTALL INSTRUCTIONS	5/98	C/12-18-00		X	X			
TFC07-0043H	5	CLASS D CARGO COMP. FPS FIREX PAN INSTALL INSTRUCTIONS	8/98	B/12-18-00						X
TFC07-0043J	2	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	A/10-16-98	X	X	X			X
TFC07-0043K	1	CLASS D CARGO COMP. FPS VERTICAL REINFORCEMENT INSTALL INSTRUCTIONS	7/05/99	IR/7-05-99	X	X	X			X
TFC07-0043K	2	CLASS D CARGO COMP. FPS VERTICAL REINFORCEMENT INSTALL INSTRUCTIONS	5/98	C/7-14-00	X	X	X			X
TFC07-0043L	1	CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	1/06/99	G/6-24-02	X					
TFC07-0043L	2	CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	1/06/99	E/6-24-02	X					
TFC07-0043L	3	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	F/12-18-00		X	X			X
TFC07-0043L	4	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	C/7-14-00		X	X			X
TFC07-0043L	5	CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	9/01/99	A/12-18-00			X			
TFC07-0043L	6	CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	9/01/99	A/12-18-00			X			
TFC07-0043L	7	CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	9/23/00	B/6-24-02	X					
TFC07-0043L	8	CLASS D CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	9/23/00	A/6-24-02	X					
TFC07-0043M	1	CLASS D CARGO COMP. FPS WIRING LAYOUT	1/06/99	B/4-23-99	X					
TFC07-0043M	2	CLASS D CARGO COMP. FPS WIRING & TUBING INSTALL INSTRUCTIONS	1/06/99	B/7-05-99	X					
TFC07-0043M	3	CLASS D CARGO COMP. FPS WIRING & TUBING INSTALL INSTRUCTIONS	1/06/99	C/12-04-01	X					
TFC07-0043M	4	CLASS D CARGO COMP. FPS WIRING & TUBING INSTALL INSTRUCTIONS	1/06/99	A/7-05-99	X					
TFC07-0043M	6	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	D/9-01-99		X	X			X
TFC07-0043M	7	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	F/7-14-00	X	X	X			X
TFC07-0043M	8	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	C/11-18-98		X	X			X
TFC07-0043M	9	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	B/11-06-01		X	X			X
TFC07-0043M	10	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	B/6-04-99		X	X			X
TFC07-0043M	11	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	9/01/99	IR/9-01-99			X			
TFC07-0043M	12	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	9/01/99	A/12-04-01			X			
TFC07-0043M	13	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	9/01/99	IR/9-01-99			X			
TFC07-0043N	1	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	I/7-05-05	X	X	X			X
TFC07-0043N	1a	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	1/06/99	G/7-05-05	X	X	X			X
TFC07-0043N	1b	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	1/06/99	F/10-20-10	X	X	X			X
TFC07-0043N	2	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	D/7-05-99	X	X	X			X
TFC07-0043N	3	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	H/7-05-99	X	X	X			X
TFC07-0043N	4	CLASS D CARGO COMP. FPS TUBING DETAILS	8/98	E/7-05-99	X	X	X			X
TFC07-0043N	5	CLASS D CARGO COMP. FPS TUBING DETAILS	1/06/99	C/9-23-00	X	X	X			X
TFC07-0043N	5a	CLASS D CARGO COMP. FPS TUBING DETAILS	1/06/99	C/2-10-00	X	X	X			X
TFC07-0043N	5b	CLASS C CARGO COMP. FPS TUBING DETAILS	9/01/99	C/10-20-10			X			
TFC07-0043N	6	CLASS D CARGO COMP. FPS TUBING/WIRING SUPPRESSION RACK INSTALL INSTRUCTIONS	5/98	C/1-06-99		X	X			X
TFC07-0043N	7	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	E/7-05-05		X	X			
TFC07-0043N	8	CLASS C CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	F/7-05-05		X	X			
TFC07-0043N	9	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	A/10-14-98		X	X			
TFC07-0043N	10	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	B/9-01-99		X	X			
TFC07-0043N	11	CLASS C CARGO COMP. FPS TUBING ROUTING & INSTALL INSTRUCTIONS	8/98	E/7-05-05						X
TFC07-0043N	12	CLASS C CARGO COMP. FPS TUBING ROUTING & INSTALL INSTRUCTIONS	8/98	C/7-05-05						X
TFC07-0043N	13	CLASS D CARGO COMP. FPS TUBING ROUTING INSTRUCTIONS	8/98	IR/10-12-98						X

DRAWING	SHEET NO.	TITLE	DATE	REVISION / DATE	A/C CONFIGURATION					
					BOEING 737 200 SERIES	BOEING 737 300 SERIES	BOEING 737 300 ER SERIES	BOEING 737 400 SERIES	BOEING 737 400 ER SERIES	BOEING 737 500 SERIES
TFC07-0043N	14	CLASS D CARGO COMP. FPS TUBING ROUTING INSTRUCTIONS	8/98	IR/10-15-98						X
TFC07-0043N	15	CLASS D CARGO COMP. FPS TUBING & WIRING INSTALL INSTRUCTIONS SUPPRESSON RACK	1/06/99	B/4-23-99	X					
TFC07-0043N	16	CLASS C CARGO COMP. FPS TUBING ROUTING & INSTALL INSTRUCTIONS	1/06/99	C/7-05-05	X					
TFC07-0043N	17	CLASS C CARGO COMP. FPS TUBING ROUTING & INSTALL INSTRUCTIONS	1/06/99	F/7-05-05	X					
TFC07-0043N	18	CLASS D CARGO COMP. FPS TUBING ROUTING INSTALL INSTRUCTIONS	1/06/99	A/2-17-99	X					
TFC07-0043N	19	CLASS D CARGO COMP. FPS TUBING ROUTING INSTALL INSTRUCTIONS	1/06/99	B/7-05-99	X					
TFC07-0043N	20	CLASS D CARGO COMP. FPS TUBING/WIRING SUPPRESSION RACK INSTALL INSTRUCTIONS	9/01/99	IR/9-01-99			X			
TFC07-0043N	21	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	9/01/99	A/1-24-00			X			
TFC07-0043N	22	CLASS D CARGO COMP. FPS TUBING & WIRING INSTALL INSTRUCTIONS SUPPRESSON RACK	9/23/00	A/2-23-01	X					
TFC07-0043P	2	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	5/98	A/10-16-98	X	X	X			X
TFC07-0043Q	1	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	6/98	A/10-14-98	X	X	X			X
TFC07-0043Q	2	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	6/98	D/9-01-99	X	X	X			X
TFC07-0043Q	3	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	6/98	D/9-01-99		X	X			X
TFC07-0043Q	4	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	6/98	A/10-14-98		X	X			X
TFC07-0043Q	5	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	1/06/99	A/7-06-99	X					
TFC07-0043Q	6	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	1/06/99	B/4-23-99	X					
TFC07-0043Q	7	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	9/01/99	IR/9-01-99			X			
TFC07-0043Q	8	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	9/23/00	IR/9-23-00	X					
TFC07-0062A	1	CLASS C CARGO COMP. FPS ENCLOSURE/FIREX PLATE LAYOUT	12/18/00	C/2-01-10				X	X	
TFC07-0062B	1	CLASS C CARGO COMP. FPS CONTROL PANEL INSTALL INSTRUCTIONS	12/18/00	B/9-05-05				X	X	
TFC07-0062C	1	CLASS D CARGO COMP. FPS CIRCUIT BREAKER INSTALL INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062D	1	CLASS D CARGO COMP. FPS ANNUNCIATOR INSTALL INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062E	1	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062F	1	CLASS D CARGO COMP. FPS FAULT PANEL INSTALL INSTRUCTIONS	12/18/00	A/12-04-01				X	X	
TFC07-0062G	1	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	12/18/00	B/9-05-05				X	X	
TFC07-0062G	2	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	12/18/00	B/9-05-05				X	X	
TFC07-0062G	3	CLASS C CARGO COMP. FPS ENCLOSURE/FIREX PLATE LOCATION INSTRUCTIONS	12/18/00	B/12-05-02				X	X	
TFC07-0062G	4	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	12/18/00	B/4-01-03				X	X	
TFC07-0062G	5	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	12/18/00	B/4-01-03				X	X	
TFC07-0062G	6	CLASS C CARGO COMP. FPS ENCLOSURE INSTALL INSTRUCTIONS	12/18/00	B/4-01-03				X	X	
TFC07-0062H	1	CLASS D CARGO COMP. FPS FIREX PLATE INSTALL INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062H	2	CLASS D CARGO COMP. FPS FIREX PLATE INSTALL INSTRUCTIONS	12/18/00	A/12-04-01				X	X	
TFC07-0062H	3	CLASS C CARGO COMP. FPS FIREX PLATE INSTALL INSTRUCTIONS	12/18/00	B/12-05-02				X	X	
TFC07-0062J	1	CLASS D CARGO COMP. FPS INSTALL INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062K	1	CLASS D CARGO COMP. FPS VERTICAL REINFORCEMENT INSTALL INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062K	2	CLASS D CARGO COMP. FPS VERTICAL REINFORCEMENT INSTALL INSTRUCTIONS	12/18/00	A/12-04-01				X	X	
TFC07-0062L	1	CLASS C CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	12/18/00	C/12-05-02				X		
TFC07-0062L	2	CLASS C CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	12/18/00	C/12-05-02				X		
TFC07-0062L	3	CLASS C CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	12/18/00	C/12-05-02				X		
TFC07-0062L	4	CLASS C CARGO COMP. FPS SUPPRESSION RACK INSTALL INSTRUCTIONS	12/18/00	C/12-05-02				X		
TFC07-0062M	1	CLASS D CARGO COMP. FPS WIRING LAYOUT	12/18/00	A/12-04-01				X	X	
TFC07-0062M	2	CLASS D CARGO COMP. FPS WIRING HARNESS ROUTING INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062M	3	CLASS D CARGO COMP. FPS WIRING & TUBING INSTALL INSTRUCTIONS	12/18/00	A/12-04-01				X	X	
TFC07-0062M	4	CLASS D CARGO COMP. FPS WIRING & TUBING INSTALL INSTRUCTIONS	12/18/00	A/12-04-01				X	X	
TFC07-0062M	5	CLASS D CARGO COMP. FPS WIRING & TUBING INSTALL INSTRUCTIONS	12/18/00	A/12-04-01				X	X	

DATE: 03/02/98 TIME: 10:02

SEE SHEET 1 FOR REVISION DESCRIPTION

A.A.E., LTD. P.O. BOX 1117  
 BLUE SPRINGS, MO 64013  
 PHONE: (816)22

DATE: 01/03/01 TIME: 00:00

DRAWING	SHEET NO.	TITLE	DATE	REVISION / DATE	A/C CONFIGURATION					
					BOEING 737 200 SERIES	BOEING 737 300 SERIES	BOEING 737 300 ER SERIES	BOEING 737 400 SERIES	BOEING 737 400 ER SERIES	BOEING 737 500 SERIES
TFC07-0062N	1	CLASS C CARGO COMP. FPS TUBING DETAILS	12/18/00	D/7-05-05				X	X	
TFC07-0062N	2	CLASS C CARGO COMP. FPS TUBING DETAILS	12/18/00	B/12-05-02				X	X	
TFC07-0062N	3	CLASS C CARGO COMP. FPS TUBING DETAILS	12/18/00	D/7-05-05				X	X	
TFC07-0062N	4	CLASS D CARGO COMP. FPS TUBING/WRING SUPPRESSION RACK INSTALL. INSTRUCTIONS	12/18/00	A/12-04-01				X		
TFC07-0062N	5	CLASS C CARGO COMP. FPS TUBING ROUTING & INSTALL. INSTRUCTIONS	12/18/00	D/7-05-05				X	X	
TFC07-0062N	6	CLASS C CARGO COMP. FPS TUBING ROUTING & INSTALL. INSTRUCTIONS	12/18/00	D/7-05-05				X	X	
TFC07-0062N	7	CLASS D CARGO COMP. FPS TUBING/WRING SUPPRESSION RACK INSTALL. INSTRUCTIONS	12/18/00	A/12-04-01				X		
TFC07-0062P	1	CLASS D CARGO COMP. FPS INSTALL. INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062Q	1	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062Q	2	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	12/18/00	IR/12-18-00				X	X	
TFC07-0062Q	3	CLASS D CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	12/18/00	A/12-04-01				X	X	
TFC07-0062Q	4	CLASS C CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	12/18/00	B/12-05-14				X		
TFC07-0062Q	5	CLASS C CARGO COMP. FPS PLACARD LOCATION INSTRUCTIONS	12/18/00	B/12-05-14				X		
TFC07-0069	1-2	CLASS D CARGO COMP. FPS DUAL LOOP DETECTOR INSTALL. INSTRUCTIONS	1/24/01	C/9-05-05	X	X	X	X	X	X
TFA09-0041		AIRPLANE FLIGHT MANUAL SUPPLEMENT (MANUAL CONTROL PANEL, 60 MINUTE SYSTEM)	7/98	G/8-13	X	X		X		X
TFA09-0044		AIRPLANE FLIGHT MANUAL SUPPLEMENT (MANUAL CONTROL PANEL, 140 MINUTE SYSTEM)	4/00	B/8-13			X		X	
TFA09-0050		AIRPLANE FLIGHT MANUAL SUPPLEMENT (AUTOFIRE CONTROL PANEL, 60 MINUTE SYSTEM)	6/00	A/2-01	X	X		X		X
TFA09-0058		AIRPLANE FLIGHT MANUAL SUPPLEMENT (AUTOFIRE CONTROL PANEL, 140 MINUTE SYSTEM)	1/01	IR/2-01			X		X	
TFA11-0004	1	ELIGIBILITY LIST	5/98	D/12-18-00	X	X	X	X	X	X
TFC12-0053-( )	1	SPEC. CONTROL DWG., DETECTION/SUPPRESSION CONTROL PANEL (2 CARGO COMPARTMENTS)	5/98	E/02-02-09	X	X	X	X	X	X
TFC12-0056-( )	1	FAULT PANEL ASSEMBLY	3/98	H/11-19-01	X	X	X	X	X	X
TFC12-0056-( )	2	FAULT PANEL ASSEMBLY	6/98	F/11-19-01	X	X	X	X	X	X
TFC12-0056-( )	3	FAULT PANEL ASSEMBLY	6/98	E/12-05-00	X	X	X	X	X	X
TFC12-0056-( )	4	FAULT PANEL ASSEMBLY	6/98	D/11-19-01	X	X	X	X	X	X
TFC12-0057	1	SPECIFICATION CONTROL DWG. FAULT PANEL ASSEMBLY	5/98	D/9-20-99	X	X	X			X
TFC12-0061-( )	2	SPEC. CONTROL DWG., DETECTION/SUPPRESSION CONTROL PANEL (2 CARGO COMPARTMENTS)	1/05/00	B/12-05-08	X	X	X	X	X	X
TFC12-0068	1	SPECIFICATION CONTROL DWG. FAULT PANEL ASSEMBLY	12/18/00	IR/12-18-00				X	X	
TFC13-0023-( )	1	SPEC. CONTROL DWG, DETECTOR	5/98	F/02-11-09	X	X	X	X	X	X
TFC13-0024-( )	1	SPECIFICATION CONTROL DWG, SMOKE DETECTOR	7/07/00	I/01-30-14	X	X	X	X	X	X
TFC14-0039-( )	1	SPECIFICATION CONTROL DWG, BOTTLE ASSEMBLY, EXTINGUISHER	9/97	I-04/06/16	X	X	X	X	X	X
TFC14-0041-( )	1	SPECIFICATION CONTROL DWG, BOTTLE ASSEMBLY, EXTINGUISHER	7/30/99	B-04/06/16			X		X	
TFC14-0046-( )	1	SPECIFICATION CONTROL DWG, FILTER, INLINE ASSY	08/29/99	B-04/06/16	X		X		X	
TFC14-0047-( )	1	SPECIFICATION CONTROL DWG, BOTTLE ASSEMBLY, EXTINGUISHER WITH INTERNAL DRYER	5/08/00	IR/5-08-00	X	X	X	X	X	X
TFC14-0049-( )	1	SPECIFICATION CONTROL DWG, BOTTLE ASSEMBLY, EXTINGUISHER WITH INTERNAL DRYER	1/26/01	A-04/06/16			X		X	
TFA15-0003-( )-( )	1	BULKHEAD NOZZLE	2/79	I/8-31-02	X	X	X	X	X	X
TFC15-0016-( )	1	SPECIFICATION CONTROL DWG. FIREX NOZZLE	12/97	I-04/06/16	X	X	X	X	X	X
TFC15-0017-( )	1	SUSTAINING NOZZLE	06/01/11	IR/06-01-11	X	X	X	X	X	X
TFC16-0026-( )	1	SPECIFICATION CONTROL DWG, METERING ASSEMBLY	9/97	K-04/06/16	X	X	X	X	X	X
TFC16-0029-( )	1	SPECIFICATION CONTROL DWG, DIVERTER VALVE ASSY, 2 OUTLET	3/98	G-04/06/16	X	X	X	X	X	X
TFA17-0049		GROUND FUNCTIONAL TEST PLAN	5/98	A/6-98	X	X	X	X	X	X
TFA17-0051		INSTRUMENTATION PLAN	3/98	IR/3-98	X	X	X	X	X	X
TFA17-0053		FLIGHT TEST PLAN	5/98	IR/5-98	X	X	X	X	X	X
TFA17-0069		FLAME PENETRATION RESISTANCE TEST PROPOSAL	3/02	A/3-19-02	X	X	X	X	X	X
TFA18-0089		SMOKE DETECTION AND FIRE SUPPRESSION SYSTEM INSTRUCTIONS FOR CONTINUED AIRWORTHINESS FOR B737-200/300/400/500 SERIES	8/98	D/12-04-09	X	X	X	X	X	X
TFA18-0091		STRUCTURAL SUBSTANTIATION REPORT	7/98	E/3-10-05	X	X	X	X	X	X
TFA18-0093		SAFETY ASSESSMENT REPORT	7/98	IR/7-98	X	X	X	X	X	X
TFA18-0095		ENVIRONMENTAL COMPLIANCE REPORT	7/98	C/10-19-05	X	X	X	X	X	X
TFA18-0097		TEST REPORT CARGO FPS	3/98	B/10-31-03	X	X	X	X	X	X
TFA18-0099		FLAMMABILITY REPORT	6/98	IR/6-19-98	X	X	X	X	X	X
TFA18-0100		ELECTRICAL LOAD SUMMARY REPORT	6/98	IR/6-98	X	X	X	X	X	X
TFA18-0102		ALTERATION COMPLIANCE SUMMARY REPORT	7/98	B/9-29-04	X	X	X	X	X	X
TFA18-0139		BURN TEST REPORT	5/02	IR/5-22-02	X	X	X	X	X	X
TFA18-0159		WEIGHT INFORMATION REPORT FOR EQUIPMENT ADDED BY THE AAE, LTD SMOKE DETECTION/FIRE SUPPRESSION SYSTEM ON THE B737-200, -300, -400, -500 SERIES	11/09	IR/11-20-09	X	X	X	X	X	X
TFA18-0205		MAINTENANCE MANUAL SMOKE DETECTION/FIRE SUPPRESSION SYSTEM B737-200 SERIES	11/09	IR/11-25-09	X					
TFA18-0206		MAINTENANCE MANUAL SMOKE DETECTION/FIRE SUPPRESSION SYSTEM B737-300/-500 SERIES	11/09	IR/11-25-09		X	X			X
TFA18-0207		MAINTENANCE MANUAL SMOKE DETECTION/FIRE SUPPRESSION SYSTEM B737-400 SERIES	11/09	IR/11-25-09				X	X	
TFA18-0211		RECOMMENDED CHANGES TO THE MASTER MINIMUM EQUIPMENT LIST FOR BOEING B737-200, -300, -400, -500 SERIES AAE LTD SMOKE DETECTION/FIRE SUPPRESSION SYSTEM	12/09	IR/12-04-09	X	X	X	X	X	X
TFA21-0019		ENGINEERING ORDER	2/01	B/12-01-04	X	X	X	X	X	X
SL 26-6		LOADING OF CARGO COMPARTMENT TO INSURE PROPER FUNCTIONING OF THE AAE CARGO FIRE SUPPRESSION SYSTEM (FPS)	5/01/14	IR/5-01-14	X	X	X	X	X	X

SEE SHEET 1 FOR REVISION DESCRIPTION

A.A.E., LTD. P.O. BOX 1117  
BLUE SPRINGS, MO 64013  
PHONE: (816)228-3322

TITLE: DRAWING LIST

DWG. NO.: TFA10-0053

MODEL: BOEING 737 SERIES

EFFECTIVITY: AS SHOWN FILE NO. 1000533  
SHEET: 3 of 4 REV: MM

DATE: 12/13/01 TIME: 00:00

**KIT OPTION CODE**

'A'  
'B'  
'D'  
'E'  
'F'  
'G'  
'H'  
'J'  
'K'  
'L'  
'M'  
'N'  
'P'  
'Q'  
'U'  
'V'

**KIT OPTION IDENTIFICATION**

AUTOFIRE CONTROL PANEL & DETECTION/SUPPRESSION MASTER KIT (MIL SPEC WIRE)  
 MANUAL CONTROL PANEL & DETECTION/SUPPRESSION MASTER KIT (MIL SPEC WIRE)  
 AIRCRAFT EQUIPPED WITH AUXILIARY FUEL TANKS  
 FIRE EXTINGUISHER BOTTLES CONTAINING METHONAL  
 FIRE EXTINGUISHER BOTTLES NOT CONTAINING METHONAL  
 TFC13-0024-3 DUAL CHANNEL DETECTORS  
 FLARED FITTINGS - SUPPRESSION TUBING  
 COMPRESSION FITTINGS - SUPPRESSION TUBING  
 WIRING HARNESS MASTER KIT W/ EXPANDABLE SLEEVING  
 AUTOFIRE CONTROL PANEL RELOCATION KIT  
 SUPPRESSION RACK RELOCATION TO RIGHT-HAND SIDE OF AIRCRAFT  
 ADF EXTENSION HARNESS KIT  
 FUEL FLOW PWR SUPPLY EXTENDER HARNESS  
 F.S. 540 WING SECTION FRONT SPAR VERTICAL REINFORCEMENT  
 AUTOFIRE CONTROL PANEL & DETECTION/SUPPRESSION MASTER KIT (BMS SPEC WIRE)  
 MANUAL CONTROL PANEL & DETECTION/SUPPRESSION MASTER KIT (BMS SPEC WIRE)

KIT OPTIONS	DRAWINGS NOT APPLICABLE FOR THIS OPTION	DRAWING APPLICABLE FOR THIS OPTION
'A'	TFC03-0136 SHT. 1 TFC03-0138 SHT. 1 TFC03-0152-(101)/(201) SHT. 1 TFC03-0249-(201) SHT. 1 TFC03-0256-(201) SHT. 1 TFC03-0314 SHTS. 1-7 TFC03-0315 SHT. 1 TFC03-0316 SHTS. 1-7 TFC12-0053-(5) SHT. 1 TFA09-0041 TFA09-0044	TFC03-0152-(301)/(401) SHT. 1 TFC03-0198 SHT. 1 TFC03-0199 SHT. 1 TFC03-0200 SHT. 1 TFC03-0207-(101) SHT. 1 TFC03-0213 SHT. 1 TFC03-0249-(101) SHT. 1 TFC03-0250 SHTS. 1-7 TFC03-0251 SHT. 1 TFC03-0256-(101) SHT. 1 TFC03-0257 SHTS. 1-7 TFC12-0061-(4) SHT. 1 TFA09-0050 TFA09-0058
'B'	TFC03-0152-(301)/(401) SHT. 1 TFC03-0198 SHT. 1 TFC03-0199 SHT. 1 TFC03-0200 SHT. 1 TFC03-0207-(101) SHT. 1 TFC03-0213 SHT. 1 TFC03-0249-(101) SHT. 1 TFC03-0250 SHTS. 1-7 TFC03-0251 SHT. 1 TFC03-0256-(101) SHT. 1 TFC03-0257 SHTS. 1-7 TFC12-0061-(4) SHT. 1 TFA09-0050 TFA09-0058	TFC03-0136 SHT. 1 TFC03-0138 SHT. 1 TFC03-0152-(101)/(201) SHT. 1 TFC03-0249-(201) SHT. 1 TFC03-0256-(201) SHT. 1 TFC03-0314 SHTS. 1-7 TFC03-0315 SHT. 1 TFC03-0316 SHTS. 1-7 TFC12-0053-(5) SHT. 1 TFA09-0041 TFA09-0044
'D'	NONE	ALL
'E'	TFC14-0047-(1) SHT. 1 TFC04-0049-(1) SHT. 1	TFC14-0039-(1) SHT. 1 TFC14-0041-(1) SHT. 1
'F'	TFC14-0039-(1) SHT. 1 TFC14-0041-(1) SHT. 1	TFC14-0047-(1) SHT. 1 TFC04-0049-(1) SHT. 1
'G'	TFC13-0023-(1)/(2) SHT. 1	TFC07-0069 SHTS. 1-2 TFC13-0024-(3) SHT. 1 TFA21-0019 SHTS. 1-5
'H'	NONE	ALL
'J'	NONE	ALL
'K'	TFC03-0152-(101)/(201)/(301)/(401) SHT. 1	TFC03-0154-(101)/(102)/(103)/(104) SHT. 1
'L'	NONE	TFC03-0203-(101) SHT. 1 TFC03-0204-(101) SHT. 1 TFC03-0205-(101) SHT. 1 TFC03-0206-(101) SHT. 1
'M'	TFC06-0080-(101) SHT. 1 TFC06-0083-(101) SHT. 1 TFC06-0084-(101) SHT. 1 TFC06-0085-(101) SHT. 1 TFC06-0089 SHT. 1 TFC06-0091 SHT. 1 TFC07-0043L SHTS. 1-2 TFC07-0043N SHT. 15 TFC07-0043Q SHT. 6	TFC03-0212-(101) SHTS. 1-2 TFC03-0223-(101) SHTS. 1-2 TFC06-0055 SHT. 1 TFC06-0080-(102) SHT. 2 TFC06-0083-(102) SHT. 2 TFC06-0084-(102) SHT. 2 TFC06-0085-(102) SHT. 2 TFC06-0089 SHT. 2 TFC06-0091 SHT. 2 TFC06-0112 SHT. 1 TFC07-0043L SHTS. 7-8 TFC07-0043N SHT. 22 TFC07-0043Q SHT. 8
'N'	NONE	TFC03-0148 SHT. 1 TFC03-0150 SHT. 1
'P'	NONE	TFC03-0159 SHT. 1
'Q'	NONE	TFC06-0097 SHT. 1 TFC07-0043K SHTS. 1-2 TFC07-0062K SHTS. 1-2
'U'	TFC03-0249-(101)/(301)/(401) SHT. 1 TFC03-0256-(101)/(301)/(401) SHT. 1 TFC03-0314 SHTS. 1-7 TFC03-0315 SHT. 1 TFC03-0316 SHTS. 1-7 TFC12-0053-(5) SHT. 1 TFA09-0041 TFA09-0044	TFC03-0249-(201) SHT. 1 TFC03-0250 SHTS. 1-7 TFC03-0251 SHT. 1 TFC03-0256-(201) SHT. 1 TFC03-0257 SHTS. 1-7 TFC12-0061-(4) SHT. 1 TFA09-0050 TFA09-0058
'V'	TFC03-0249-(101)/(201)/(301) SHT. 1 TFC03-0250 SHTS. 1-7 TFC03-0251 SHT. 1 TFC03-0256-(101)/(201)/(301) SHT. 1 TFC03-0257 SHTS. 1-7 TFC12-0061-(4) SHT. 1 TFA09-0050 TFA09-0058	TFC03-0249-(401) SHT. 1 TFC03-0256-(401) SHT. 1 TFC03-0314 SHTS. 1-7 TFC03-0315 SHT. 1 TFC03-0316 SHTS. 1-7 TFC12-0053-(5) SHT. 1 TFA09-0041 TFA09-0044

**KIT NUMBERS**

- 1 TFK B737-200 (-100) 'A', 'B', 'U', OR 'V'; 'E' OR 'F'; 'H' OR 'J'; AND/OR 'G'; 'K'; 'L'; 'M'; 'P'; 'Q'
- 2 TFK B737-300 (-200) 'A', 'B', 'U', OR 'V'; 'E' OR 'F'; 'H' OR 'J'; AND/OR 'D'; 'G'; 'K'; 'L'; 'N'; 'Q'
- 3 TFK B737-300 (-300) 'A', 'B', 'U', OR 'V'; 'E' OR 'F'; 'H' OR 'J'; AND/OR 'D'; 'G'; 'K'; 'L'; 'N'; 'Q'
- 4 TFK B737-400 (-400) 'A', 'B', 'U', OR 'V'; 'E' OR 'F'; 'H' OR 'J'; AND/OR 'G'; 'L'; 'Q'
- 5 TFK B737-400 (-500) 'A', 'B', 'U', OR 'V'; 'E' OR 'F'; 'H' OR 'J'; AND/OR 'G'; 'L'; 'Q'
- 6 TFK B737-500 (-600) 'A', 'B', 'U', OR 'V'; 'E' OR 'F'; 'H' OR 'J'; AND/OR 'D'; 'G'; 'K'; 'L'; 'Q'

SEE SHEET 1 FOR REVISION DESCRIPTION

A.A.E., LTD. P.O. BOX 1117  
 BLUE SPRINGS, MO 64013  
 PHONE: (816)228-3322

TITLE: DRAWING LIST

DWG. NO.: TFA10-0053

MODEL: BOEING 737 SERIES

EFFECTIVITY: AS SHOWN FILE NO. 1000534 SHEET: 4 of 4 REV: MM